

FSB ASL® kit

Angular backplates


■ Aluminium
■ Stainless steel
■ Bronze

12 1410 

Long angular backplate, PC, WL, WC
(concealed fixing)

C = centres; for possible keyways and centres, see page 387 ff.

The unlocking device and indicator are available in the accessory bag, which must be ordered separately.



For accompanying accessory bags, see page 348 ff.